

Table of Contents:

| | |
|--|-------|
| 1. SAFETY | |
| 1.1 General safety precautions and Safety instructions | 3 |
| 2. TRANSPORTATION, HANDLING AND STORAGE | |
| 2.1 Transportation and Handling..... | 4 |
| 2.2 Storage..... | 4 |
| 2.3 Response to emergency situations | 5 |
| 3 PRODUCT INTRODUCTIONS | |
| 3.1 Technical data | 5 |
| 4. INSTALLATION | |
| 4.1 Tools and material list for installation..... | 6 |
| 4.2 Inspection before installation..... | 6-7 |
| 4.3 Installation Location..... | 7 |
| 4.4 Installation Steps..... | 7-8 |
| 4.5 Connection Terminals..... | 8 |
| 4.6 Mounting Hardware..... | 8-9 |
| 4.7 Final Connection of the Installation..... | 10 |
| 5. PARALLEL CONNECTION..... | 10-11 |
| 6. Retrofitting..... | 11 |
| 7. OPERATING | |
| 7.1 Operating environment..... | 11 |
| 7.2 Charging..... | 11-12 |
| 7.2.1 Charging stage | 12 |
| 7.3 Discharging | 12 |
| 7.4 Parameter set up guide in Charger/Inverter | 12-13 |
| 8. TROUBLE SHOOTING..... | 13-14 |
| 9. SERVICE AND MAINTENANCE..... | 14 |